



PHASE

SHUTTER UPS

Shutter Uninterruptible Power Supplies from **1000-1500W**



WALL MOUNT



PLUG&PLAY



EASY
SERVICE



HOME/OFFICE



EMERGENCY



KOMPLEXES

SHUTTER UPS

Shutter UPS is specially designed for shutter motors and is capable of operating any motor used in this structure. Compared to other uninterruptible power sources, it can turn on and off 10-15 times more during power cuts. In this way, it uses the completely maintenance-free dry type batteries within the maximum time.

- ◆ Shutter and UPS control via one remote control
- ◆ 50-100 (Optional) hours of standby time
- ◆ Easy to install thanks to its small and elegant design
- ◆ Micro processor controlled
- ◆ Ability to introduce up to 60 remote controls
- ◆ Controlling 2 shutters with modern 2-channel remote control
- ◆ Operates in Hi and Low Voltage (165 VAC - 240Vac)
- ◆ Led and audial alerts
- ◆ Remote control from 30 meters

SHUTTER UPS

MODEL	SHT 1000	SHT 1500
Capacity (Watt)	1000	1500
Input Voltage & Frequency	220, 230 , 240 Vac 1Ph+N+PE / 50-60 Hz	
Output Voltage & Frequency	220, 230 , 240 Vac 1Ph+N+PE / 50-60 Hz	
Number of Output	1 (2. output optional)	
Line Operation Range	165 - 250 Vac	
RF Operating Frequency	433,92 MHZ	
Battery Type	No Maintenance Dry Type	
Number of Batteries	2 pcs 12V 7 Ah	2 pcs 12V 9 Ah (4* 12V 7 Ah Optional)
Charge Time	10 h	
Standby Time	50 hr	65 hr (100 hr Optional)
Remote Control Distance	30 m	
Displays	Mains - Battery - Alerts	
Alarm & Warnings	No mains warning, operation from the battery warning, Over load warning, battery charge warning, battery high warning	
Protections	Over load protection, short circuit protection, over battery protection	
Altitude	<1000m	
Operation Temperature	0°C - 40°C	
Net & Lifting Weight	12,5 kg	17 kg
Dimensions (HxDxW) mm	340 x 243 x 108	
Options	60 pcs Remote Control	

The company reserves the right to change specifications and designs without notice.



INNOVATIVE ENERGY SYSTEMS

www.innovasis.com.tr

The company reserves the right to change specifications and designs without notice.